

# **STEPS FOR CONFIGURING BLUETOOTH IN AT COMMAND MODE**

## **Step 1:**

Take an USB to Serial converter, connect RX pin of Bluetooth to TX pin of Serial adapter and connect TX pin of Bluetooth to RX pin of Serial adapter.

## **Step 2:**

Connect the Serial adapter to the PC through a USB cable. To establish communication through serial software's like TERA TERM. The Serial software must have an option to include a CR+LF at end of every line command.

Link to download Tera Term: <http://logmett.com/index.php?/download/tera-term-483-freeware.html>


## **Step 3:**

To configure in AT mode first enable key pin with 3.3 volts. Then connect the ground and VCC (3.6-6V) pins of the Bluetooth module.

Note: If we follow this in sequence then the Red LED will glow once in two seconds. This indicates it is in AT command mode. If not repeat the step 3 again


## **Step 3:**

Now Open the Tera Term software and open a new connection. Select Serial connection and the respective com port of USB attached in above steps. We can check the USB com port from device manager.



#### Step 4:

Then open setup menu and terminal window in it. Set new line transmit as CR+LF. And enable Local Echo. Press OK.




#### Note:

- Local echo is to display the transmit character on screen.
- CR+LF is carriage return + line feed necessary to send AT commands

### Step 5:

Open the setup menu and Serial Port window in it. And set Baud rate to 38400. Press OK.




### Note:

- The default Baud rate for AT command mode is 38400.

## Step 6:

Now type the AT commands from the Datasheet into the workspace and verify the outputs.

A screenshot of a Tera Term VT window titled "COM4:38400baud - Tera Term VT". The window has a menu bar with "File", "Edit", "Setup", "Control", "Window", and "Help". The main area is a black terminal window with white text. The text shows the following sequence: "at" followed by "OK" on a new line. Then "at+version?" followed by "+VERSION:2.0-20100601" on a new line, and finally "OK" on a new line. Red underlines are visible under the "at" and the final "OK".

```
at
OK
at+version?
+VERSION:2.0-20100601
OK
```

## Note:

- If you get an error resend the AT command and if the error still persists check the connections.

# **STEPS FOR CONFIGURING BLUETOOTH IN TRANSPARENT MODE**

## **Step 1:**

Take an USB to Serial converter, connect RX pin of Bluetooth to TX pin of Serial adapter and connect TX pin of Bluetooth to RX pin of Serial adapter.

## **Step 2:**

Connect the Serial adapter to the PC through a USB cable. To establish communication through serial software's like TERA TERM. The Serial software must have an option to include a CR+LF at end of every line command.


Link to download Tera Term: <http://logmett.com/index.php?/download/tera-term-483-freeware.html>

## **Step 3:**

To configure in Transparent mode connect the ground and VCC (3.6-6V) pins of the Bluetooth module and connect the key pin to ground.


## **Step 3:**

Now Open the Tera Term software and open a new connection. Select Serial connection and the respective com port of USB attached in above steps. We can check the USB com port from device manager.



#### Step 4:

Then open setup menu and terminal window in it. Set new line transmit as CR+LF. And enable Local Echo. Press OK.




**Note:**

- Local echo is to display the transmit character on screen.
- CR+LF is carriage return + line feed necessary to send AT commands
- In new line receive can be made carriage return or carriage return + line feed or auto

### Step 5:

Open the setup menu and Serial Port window in it. And set Baud rate to 9600. Press OK.




### Note:

- The default baud rate for transparent command mode is 9600.

### Step 6:

Now if you pair the Bluetooth with a mobile and connect in any Bluetooth terminal software in mobile, you can communicate between the mobile and the PC.

In PC



In mobile

